

Electrofusion Installation Checklist

(1) Before Starting

Before leaving for a job site, do a tool check and make sure that you have everything on-hand before starting.

- Pipe Measuring Tools
- Pipe Marking Tools
- Pipe Cutting Tools
- Pipe Cleaning Material
- Pipe Scraping Tools
- Pipe Restraint & Alignment Tools

- Pipe Re-Rounding Tools
- Pipe Beveling Tools
- Appropriately Sized Power Source & Extra Fuel

Phone: 770.632.7530

Toll Free: 888.770.6330

www.integrityFusion.com

- Extension Cords
- Joint Inspection Tools
- EF Processor

When at the job site.

- . Inspect the work site, making sure the area is dry and free of obstructions and potential hazards.
- In case of severe weather, follow established inclement weather procedures before continuing.
- Initial cleaning of the pipe surfaces can be done with clean water prior to pipe preparation if needed. An area 2X the couplers length or 3X the Saddles length should be cleaned.
- **DO NOT** continue with the fusion process if there is any water coming into direct contact with the fusion area. Any flowing water coming into contact with the fusion zones during assembly and fusion must be avoided.

(2) Verify Pipe Ends Are Within Required ASTM Outside Diameter Specs

Before continuing, make sure that the pipe being used is the correct size for the electrofusion fitting by verifying that both sides of
the pipe are within spec. If the pipe is not within spec DO NOT continue and contact the project manager at once.

(3) Check Pipe Surface for Excessive Gouges and Flat Spots

• If there are flat spots in the area where the fitting is to be fused or if there are gouges that exceed 10% of the pipe's minimum wall thickness, cut the pipe back.

(4) For Coupler Installations - Check Pipe Ends for Excessive Toe-In

• Toe-in should not exceed more than 2" from the pipe end. If it is found to exceed more than 2" from the end of the pipe, the pipe end must be cut back to a point beyond where the toe-in ends before proceeding.

(5) For Coupler Installations - Cut the Pipe Ends

• Pipe ends must be cut square and at right angles to the pipe axis and as close to a 90° angle as possible. On larger pipes that must be cut by hand, it may be necessary to use a strap, a clamp or some other form of device to provide a visual on the pipe surface that will help the installer guide and control his cut. When using a chainsaw to cut HDPE pipe, no lubricant of any kind can be used in the chainsaw.

(6) For Coupler Installations - Mark Your Stab Depth and Coupling Length

• Mark the stab depth on the pipe surface by first measuring the total length of the electrofusion coupler and then place a mark on the surface of the pipe that is ½ the total length of the coupler and then place a second mark showing the full length of the coupler.

(7) For Sidewall Installations – Identify the Fitting Location and Orientation

Leaving the fitting in its packaging, clearly mark the pipe surface area where the fitting is to be installed.

(8) Check the Pipe for Excessive Out-of-Round Condition

For Coupler Installation

- To check for an out-of-round condition, the pipe ends must be measured horizontally and vertically with a tape measure to find the high and low points of the pipe. The difference between the high and low diameters should not exceed ¼".
- If the difference is greater than ¼" then a full encirclement re-rounding clamp should be placed to the outside of the mark showing the couplers stab depth, or the mark showing the full length of the coupler. Pressure should be applied to the re-rounding clamp in this area until the pipe end is brought back into tolerance. This will make it easier to put the coupler onto the pipe, but it will also ensure the gap between the pipe and the fitting will not be too large to fill during the fusion process.

For Sidewall Fitting Installation

• If the pipe is out of round in the area where a sidewall fitting is to be installed it may be necessary to use a re-rounding device on both sides of the fitting to ensure that the contour of the pipe surface can be fused onto.

NTEGRITY Fusion Products, Inc.

Electrofusion Installation Checklist

(9) Mark the Area Where the Fitting Will be Fused.

After you have completed re-rounding the areas to be fused on the pipe, use your approved marking tool and clearly highlight the
fusion area to be peeled.

(10) Scrape the Pipe

- Using an appropriate "peeler" type of scraper and remove the surface material from the pipe, carefully inspecting the entire
 circumference of the of the area as it is being scraped, visually checking for high and low spots that may need special attention and
 to make sure that that your scraper is providing you with adequate scraping coverage.
- Take care not to inadvertently re-contaminate the freshly scraped area by touching, handling, placing tools or other items on it, or getting it wet, etc.
- Make sure to re-apply stab depth marks on the pipe surface showing both the couplers stab depth and the full coupler lengths.
- Abrasives such as sandpaper and emery cloth, files and rasps, hand scrapers, grinding wheels and wire wheels are not to be used!

(11) Re-Check for Out-of-Round Conditions

 Check the pipe ends for any adjustments that may need to be made for an out-of-round condition before trying to insert the coupler onto the pipe end.

(12) For Coupler Installation - De-burr and Bevel Pipe Ends

Using a hand scraper, or a router with a 22.5-degree angle bit for larger pipe, bevel the edges of the pipe.

(13) Final Cleaning of the Fusion Zone and Fitting

- Clean the freshly scraped fusion zone on the pipe using a 90% or greater solution of Isopropyl Alcohol with no additives and a clean, non-dyed, lint free cloth or wipe.
- Remove the electrofusion fitting from its protective packaging and wipe down the fusion zone on the inside of the fitting using the same 90% or greater solution of Isopropyl Alcohol with no additives and a clean, non-dyed, lint free cloth or wipe.
- If the prepared area is not to be assembled immediately, a plastic bag, clean plastic sheeting or shrink wrap, can be used to cover the scraped area on the pipe and the fitting can be placed back into its original plastic packaging until the assembly is to be made.

(14) Begin Fitting Assembly

For Coupler Installation

- Remove the coupler from its packaging and push the IntegriFuse Coupler onto the pipe end until the edge of the coupler that is on the pipe is aligned with the stab depth witness mark. If you are doing a repair type of fusion, you will push the coupler on until you are aligned with the full coupler length witness mark and then pull the couple back until the stab mark is visible. The weight of the fitting or the tight tolerance of the pipe OD may make it necessary to use a rubber mallet, a dead blow hammer, or a sledgehammer with wooden blocks, to carefully nudge the fitting onto the pipe.
- To control bending stresses do not let the pipes support their own weight in the coupler. To provide an unstressed assembly, it is recommended to use a suitable holding device. Maintain this stress-free condition all the way through the cooling period.

For Sidewall Fitting Installation

- Remove the Saddle Fitting from its packaging and orient the fitting and firmly place the IntegriFuse Saddle onto the prepared area where it is to be installed. Do Not Tap the Pipe Prior to Installing the Saddle!
- Using the proper restraint device, tighten the saddle down onto the surface of the pipe.

(15) Check for Excessive Gaps

- Using a flashlight and a 7" long electrical tie or something similar; check the gap around the entire circumference of the pipe and fitting when fusing a coupler. The gap should be evenly spaced and no wider than 5mm (approx. 1/4").
- When fusing a sidewall fitting, check for gaps around the entire base of the saddle. You should not be able to push your electrical tie underneath the fitting at any point.

(16) Start Fusion Sequence

- · Verify that the electrofusion processor switch is in the off position.
- Make sure that your generator is fueled, working normally and running at full throttle.
- Turn on the processor and wait for software initialization to complete. When prompted, press START to begin.

Phone: 770.632.7530

Toll Free: 888.770.6330

www.integrityFusion.com